How to change air filter on **Fiat Punto 188** – replacement guide

VIDEO TUTORIAL



Important!

This replacement procedure can be used for:
FIAT Punto II Hatchback (188) 1.2 60, FIAT Doblo I Estate (119, 223) 1.2, FIAT Doblo I Cargo (223) 1.2, FIAT Punto II Van (188) 1.2 60, FIAT Punto II Hatchback (188) 1.2 Natural Power, FIAT Punto II Hatchback (188) 1.2 Bipower (188BXA1A), FIAT Punto II Van (188) 1.2 Natural Power (188CXA1A), FIAT Punto II Hatchback (188) 1.2 Natural Power (188BXA1A)

The steps may slightly vary depending on the car design.

REPLACEMENT: AIR FILTER – FIAT PUNTO 188. TOOLS YOU'LL NEED:



- Drive socket # 10
- Ratchet wrench
- Phillips screwdriver
- Microfibre towel
- Fender cover

BUY TOOLS

Replacement: air filter – Fiat Punto 188. Tip from AUTODOC:

- Follow the terms, recommendations and requirements of the part operation provided by the manufacturer.
- Please note: all work on the car – Fiat Punto 188 – should be done with the engine switched off.

CARRY OUT REPLACEMENT IN THE FOLLOWING ORDER:

1 Open the bonnet.



2 Use a fender protection cover to prevent damaging paintwork and plastic parts of the car.




3 Unscrew the filter housing fastening bolts. Use a drive socket #10. Use a ratchet wrench.




4 Remove the air filter housing retaining spring.



5 Remove the air filter housing.



6 Undo the fastening screws of the air filter cover. Use a Phillips screwdriver.



7 Take off the filter lid.



8 Remove the filter element from the filter housing. Clean the air filter cover and housing.



Replacement: air filter – Fiat Punto 188. Professionals recommend:

- Before cleaning the air filter cover and housing, cover the air duct parts, mass airflow sensor (if available), throttle valve with a clean cloth.

9 Insert a new filter element into the filter housing. Make sure that the filter edge fits tight to the housing.



Replacement: air filter – Fiat Punto 188. Tip from AUTODOC experts:

- Check out the correct location of the filter element. Do not skew.
- Fiat Punto 188 – It's important to only use high-quality filters.
- During installation, make sure to prevent dust and dirt from getting into the air filter housing.

10 Reinstall the air filter cover. Fasten it.


11

Screw in the fastening screws of the air filter cover. Use a Phillips screwdriver.



12

Reinstall the air filter housing.




Replacement: air filter – Fiat Punto 188. AUTODOC recommends:

- Make sure the air filter body is properly seated. It should not be displaced with respect to the air intake hose of the throttle body and the guiding fasteners.

13

Screw the filter housing fastening bolts. Use a drive socket #10. Use a ratchet wrench.



14 Install the air filter housing retaining spring.



15 Remove the fender protection cover.



16 Close the hood.



WELL DONE!

VIEW MORE TUTORIALS

AUTODOC — TOP QUALITY AND AFFORDABLE CAR PARTS ONLINE

AUTODOC MOBILE APP: GREAT DEALS AND CONVENIENT SHOPPING



A GREAT SELECTION OF SPARE PARTS FOR YOUR CAR

BUY SPARE PARTS FOR FIAT

AIR FILTER: A WIDE SELECTION

CHOOSE CAR PARTS FOR FIAT PUNTO 188

AIR FILTER FOR FIAT: BUY NOW

AIR FILTER FOR FIAT PUNTO 188: THE BEST DEALS & OFFERS

ⓘ DISCLAIMER:

The document contains only general recommendations that may be useful for you when you perform repair or replacement work. AUTODOC shall not be liable for any loss, injury, damage of property occurring in the repair or replacement process due to incorrect use or misinterpretation of the provided information.

AUTODOC shall not be liable for any possible mistakes and uncertainties in this guide. The information provided is for information purposes only and cannot replace advice from specialists.

AUTODOC shall not be liable for incorrect or hazardous usage of equipment, tools and car parts. AUTODOC strongly recommends to be careful and observe the safety rules when performing repair or replacement works. Remember: usage of low quality auto parts does not guarantee you the appropriate level of road safety.